

Solar Power Bank & Light with Wireless Charger



User's Guide for Model XPC10002R v2894-01

Additional Warnings and Precautions

- **CAUTION:** TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.
- **WARNING:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain, moisture, dripping, or splashing.
- **CAUTION:** Use of controls or adjustments or performance of procedures other than those specified may result in hazardous radiation exposure.
- **WARNING:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
- **WARNING:** Do not place this unit directly onto furniture surfaces with any type of soft, porous, or sensitive finish. As with any rubber compound made with oils, the feet could cause marks or staining where the feet reside. We recommend using a protective barrier such as a cloth or a piece of glass between the unit and the surface to reduce the risk of damage and/or staining.
- **CAUTION:** Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.
- **WARNING:** There is a danger of explosion if you attempt to charge standard Alkaline batteries in the unit. Only use rechargeable NiMH batteries.
- **WARNING:** Shock hazard - Do Not Open.
- Caution and marking information is located at the rear or bottom of the apparatus.

- Objects filled with liquids, such as vases, shall not be placed on the apparatus.
- Mains plug is used as disconnect device and it should remain readily operable during intended use. In order to disconnect the apparatus from the mains completely, the mains plug should be disconnected from the mains socket outlet completely.
- Battery shall not be exposed to excessive heat such as sunshine, fire or the like.
- Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children.
- If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.
- Do not mix old and new batteries.
- Completely replace all old batteries with new ones.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (ni-cad, ni-mh, etc) batteries.
- Batteries should be recycled or disposed of as per state and local guidelines.
- **WARNING:** Lithium batteries, like all rechargeable batteries, are recyclable and should be recycled or disposed of according to state and local guidelines. They should never be disposed of in normal household waste, and they should never be incinerated, as they might explode. Contact your local government for disposal or recycling practices in your area.



WARNING: To reduce the risk of electric shock, do not remove cover (or back). No user-serviceable parts inside. Refer servicing to qualified service personnel.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of unanticipated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons.



This symbol indicates that this product incorporates double insulation between mains voltage and user accessible parts.

WARNING: DO NOT INGEST BATTERY, CHEMICAL BURN HAZARD.



WARNING : This product can expose you to chemicals including lead, which is known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov. This product meets and complies with required Federal product guidelines.


OVERVIEW

Features

- 10000mAh battery
- Type-C USB input
- Solar Panel
- Flashlight
- Micro-USB Input

Includes


- Micro-USB to USB cable
- User's Manual



POWER


Charging the Powerbank

To charge the Powerbank, plug the included Micro-USB to USB or a Type-C USB cable into one of the two **DC Power Inputs** and the other end into a powered ON computer or an AC/DC power adapter and a standard wall outlet.



Solar Panel Charging


To charge the rechargeable battery using solar power, face the solar panel toward sunlight. The **Solar Charging LED** will turn green while charging and turn off when done charging. *Note: Solar charging should only be used as a supplemental source for charging the unit. It could 50+ hours depending on weather conditions (prolonged exposure to the sun can damage the unit).*



CHARGING DEVICES


Wireless Charging

If using the **Wireless charger**, press the **Power/Flashlight** button and then place your phone onto the Power Pad to begin charging. The **Wireless Power Indicator** will turn blue, indicating it is charging the device. Note: When you press the **Power/Flashlight** button to begin charging, if no device is placed on the unit in two minutes the unit will power OFF.




USB Charging

If you want to use **USB charging**, press the **Power/Flashlight** button and plug a USB charging cable into one of the **USB Outputs** on the unit and the other end into your device. Watch Battery Indicator LEDs to see the powerbank's charge percentage. Note: When you press the **Power/Flashlight** button to begin charging, if no device is connected in two minutes the unit will power OFF.



FLASHLIGHT



Power/Flashlight

Note: The flashlight feature has 3 modes: **Solid**, **SOS** and **Strobe**.

1. To turn on the flashlight and enter Solid mode, double tap the **Power/Flashlight** button.
2. To activate rhythmic mode, press the **Power/Flashlight** button again.
3. To activate strobe mode, press the **Power/Flashlight** button again.
4. Press the **Power/Flashlight** button once more to turn off the flashlight.

INTERNATIONAL SUPPORT

To download this User's Guide in English, Spanish, or French, or to get answers to frequently asked questions, visit the support section at:

www.weather-x.com

Para descargar este Manual del Usuario en inglés, español y francés, o para obtener respuestas a preguntas frecuentes, visite la sección de apoyo en:

www.weather-x.com

Pour télécharger ce guide de l'utilisateur en anglais, espagnol ou français, ou pour obtenir des réponses à des questions fréquemment posées, consultez la rubrique d'assistance sur:

www.weather-x.com

For Warranty Information and the most up-to-date version of this User's Guide, go to:

www.weather-x.com

Customer Service: 1-888-999-4215 | Email Support: prodinfo@dpiinc.com | Email Parts: partsinfo@dpiinc.com
Copyright © 2022 Digital Products International (DPI, Inc.) All other trademarks appearing herein are the property of their respective owners. Specifications are subject to change without notice.



**Protect for Today
Sustain for Tomorrow**